Wireless USB Adapter AC1200UBE2
Quick Installation Guide

Thank you for purchasing a quality Rosewill Product.

Please register your product at : www.rosewill.com for complete warranty information and future support for your product.

1. Package Contents

Wireless USB Adapter

Driver CD

QIG



USB Cradle

* Contents: Wireless USB Adapter, Driver CD, QIG, USB Cradle
* This QIG is for Wireless USB Adapters: AC1200UBE2.

2. Hardware Connection

Plug AC1200UBE2 directly into an available USB interface on your computer. (For AC1200UBE2, you may connect it and your computer with the USB cradle included).



3. Driver Installation

3.1. Insert the Driver CD into your CD-ROM drive.



3.2. Install the provided driver from the CD.

For Windows 8/7/Vista/XP

The **Setup Wizard** on the CD will guide you through the driver installation procedures.

Simply click "**Install**". The Rosewill smart driver assistant will choose the correct driver program automatically based on your Windows operating system.

The InstallShield Wizard window will appear, then please click "**Next**" and follow the step by step procedures to finish the driver installation.

For MAC OS

Open the folder "**Driver**"> "**MAC**" from the CD.

Select the driver package according to your MAC OS version and run the **Installer.pkg** file.

Then an installation dialog will pop up. Please click "**Continue**" and follow the step by step procedures to finish the driver installation.

For Linux

You may get the available driver files from the "**Driver**" > "**Linux**" folder in the CD.

4. Connect to the Wireless Network

For Windows 8/7/Vista/XP

(Here we take Windows 7 for example.)

After driver installation, please click on the wireless network connection icon in the lower right corner of the task bar. Choose the available wireless network, and click on the "**Connect**" button to setup a wireless connection.

If the wireless network is secured, enter the security key/password in the next pop up window.

For MAC OS

Click the Wireless Network icon as below.

Choose the available wireless network, and click on the "**Connect**" button to setup a wireless connection. If the wireless network is secured, enter the network key/password in the next page.



For Linux

(Here we take Ubuntu for example.)

Choose the available wireless network to setup a wireless connection.

If the wireless network is secured, enter the password in the pop up window.



Rosewill Technical Support information

techsupport@rosewill.com